


1-8 Internal Connectors



1) ATX_12V_2X4	11) BAT
2) ATX	12) M2_32G
3) CPU_FAN	13) F_PANEL
4) SYS_FAN1/SYS_FAN2	14) F_AUDIO
5) CPU_OPT_PUMP/SYS_FAN3_PUMP	15) SPDIF_O
6) LED_C	16) F_USB30_1/F_USB30_2
7) SATA_EXPRESS	17) F_USB1/F_USB2
8) SATA3 0/1/2/3/4/5	18) TPM
9) sSATA3 0/1/2/3	19) THB_C
10) U2_32G_1/U2_32G_2	20) CLR_CMOS



Read the following guidelines before connecting external devices:

- First make sure your devices are compliant with the connectors you wish to connect.
- Before installing the devices, be sure to turn off the devices and your computer. Unplug the power cord from the power outlet to prevent damage to the devices.
- After installing the device and before turning on the computer, make sure the device cable has been securely attached to the connector on the motherboard.